



Rugged tablet EM-T195 Instruction Manual

Thanks for your to choose the new Tablet.

This guide serves to enable users to get to know and familiar with our product as soon as possible. Here we have made a brief introduction to the key layout and definitions in figures and words. And a brief explain for the basic operating functions.

Content

1. File version information
2. Device performance structure
3. Desktop layout 5-6
4. System settings



IP SYSTEMES

8 rue du Colonel Chambonnet – BP67 69672 BRON Cedex Tel.: 04 72 14 18 00 Fax: 04 72 14 18 01 www.ip-systemes.com – info@ip-systemes.fr

File N	lame	EM-T195 User Manual						
File No			0001		Edition			V1.0
Issue Date		2	021-12-	20	Page			
	Change Log							
Serial Number			Version	Change Date		Change Content		Maintenance Department
1	1 YDXX-01		V1.0	2021	-12-20	First publ	ished	Customer Service FAE Department



Device Performance Structure

Product six view



1. Power button — Press to start or close the screen display. You can use this button to put the rugged phone into sleep mode, or wake up from sleep mode.

2. Scan key — Open the scan shortcut key.

3. Barcode scanner —— Support one-dimensional code/two-dimensional code scanning.

4. Volume keys — Decrease/increase volume.

5. Front camera — 5.0MP, support photo and video.

6. Rear camera — 13.0MP, support photo and video.

7. Flash lamp —— Adjust the brightness of the light when taking pictures.

8. Speaker — Built-in speaker is used to play video and music. Embedded

 $8\Omega/1W$, waterproof speaker x 2

9. Type C —— You can exchange data through the data cable, and you can also charge the rugged mobile phone.

10. Pogo pin —— Used to connect the charging base, expand USB and the network port/charging interface.

11. SIM/TF slot —— Two out of three card holders (Micro SIM+TF or Micro SIM+Nano SIM)



Desktop Layout

Initial Desktop: Slide the arrow up and go to the desktop, as below picture.



Desktop Layout









Settings: Users can set related functions in the setting interface according to their needs, which is more convenient to use.



1. Network & internet

In this interface, you can set WiFi, Mobile network, Airplane mode, Mobile plan, Hotspot & tethering, and Advanced, etc.

Wi-Fi

search Wi-Fi AP, input password can be connected.

2:18 0		瑜 曽74%	2	2:19 🌣	88)众 自74%
÷	Network & internet	۹		÷	Wi-Fi	۹
(0	Wi-Fi Off				Use Wi-Fi	•
	Mobile network			$\widehat{\mathbf{v}}$	EM-public3F Check password and try again	₿
¥	Airplane mode			$\widehat{\mathbf{v}}$	DIRECT-HLSKY-20210119QSWmsFe	۵
	Mobile plan			\bigtriangledown	HI-LINK_3329	6
0	Hotspot & tethering Off	×		\bigtriangledown	TP-LINK_B289	×
~	Advanced Data Saver, VPN, Private DNS	-		\Diamond	2005-2	
	bala bare, mili, male bro			\bigcirc	ASUS_EmdoorVR_Test_5G	
		•		\Diamond	ChinaNet-4bDG	•
		X		\bigcirc	IPV4-5G	X
		苹		\Diamond	OTATEST_5G	#
				\Diamond	SE2020	€
				\bigcirc	SE2020_Wi-Fi5	€
				\Diamond	angel 5G	£
				+	Add network	819
					Wi-Fi preferences Wi-Fi turns back on automatically	



2. Connected devices

In this interface, you can set Bluetooth, NFC, projection, printing, Android auto, view files received by Bluetooth, etc.

1) Bluetooth Setting

Search this interface for Pair new device, and Connection preferences.

2:19 🌣	III	段 自74%	2:21	¢ III	☆ 曽73%
÷	Connected devices	۹	<i>←</i>	Pair new device	۹
+	Pair new device			Device name RD195TE	
	PREVIOUSLY CONNECTED DEVICES	~		Available devices	C
	Redmi Note 8 Pro	۲	K	Mi Smart Band 6	
>	See all		G	Phone's Bluetooth address: 00:00:04:5B:7B:11	
	Connection preferences Bluetooth, Android Auto, NFC				
()	Visible as "RD195TE" to other devices				
		8			8

2) NFC

In this interface, you can set NFC. Allow data exchange when the phone touches an NFC device. Contactless payments.



11

System setting

3. Apps & notifications

View installed APP storage space size, traffic usage, stop using APP. Set screen lock time, default notification prompt.



4. Battery

On this page, you can check battery power usage, open power saving mode and make some battery settings, as shown in the following figure.



5. Display

On this page, you can set Brightness adjustment, Night light mode, wallpaper, sleep time, interactive screen saver, font size, screen rotation switch, etc.

-	Display	م
	Brightness level	
	Dark theme Off / Will never turn on automatically	
	Night Light Off / Will never turn on automatically	
	Adaptive brightness On	
	Wallpaper	
	Screen timeout	
	Auto-rotate screen	e
	Font size Default	
	Display size Default	
	Screen saver	
	Lock screen Show all notification content	
	Lift to wake	-

6. Sound

Set media volume, alarm volume, notify volume size (can also use physical keys to the corresponding interface directly to adjust, do not disturb settings)notification ringtone settings and other operations.



7. Storage

13

View system memory usage, install and uninstall SD cards.

2:25 🏟		说 自73%
÷	Storage	م
	10.45 GB Used of 64 GB	16% used
	Storage manager	
	Photos & videos	0.33 GB
ſ	Music & audio	0.03 GB
÷."	Games	0.00
8	Movie & TV apps	0.00 GB
	Other apps	0.74 GB
	Files	0.00 GB
+	System	9.4 GB

8. Privacy

In this interface, you can view Permission manager, Show passwords, Notifications on lock screen, Autofill service from Google and Advanced.

2:25 0	: 111	滾
←	Privacy	۹
	Permission manager Control app access to your data	
	Show passwords Display characters briefly as you type Notifications on lock screen	•
	Show all notification content Autofill service from Google	
~	Saved passwords, credit cards, addresses Advanced Google location history, Activity controls, Ads, Usage & diagnostics	
		8

9. Location

In this interface, you can turn on or off GPS, allow or restrict the use of an application to obtain location information.



10. Security

In this interface, you can set screen locking mode (none, sliding, pattern, pin code, password), device management application, encryption and credentials, fixed screen, etc.



15

System setting

11. Accounts

Other accounts (Exchange, IMAP, POP3) can be added in this interface.



12. Accessibility

Some setting operations of screen reader, display and interactive controls.For example: font size, display size, dark theme, zoom in Gesture (3 consecutive clicks on the screen), color correction, color reversal, Remove the animation, press the power button to end the call, etc.



You can set the device use time, application timer, etc. you can also set parental control to help children use the device time properly.

14. DuraSpeed

DuraSpeed accelerates the speed of foreground applications by inhibiting the activities of background applications, but some notifications may not be accepted normally.



2:31 💠 🎟	說 🔒 72%
DuraSpeed	:
On	
DuraSpeed helps boost the foreground app by restricting background apps, notifications may be postponed or not received.	some
DuraSpeed does not restrict background activities of apps switched on in th	e list.
Switch on to allow apps to run in background.	
🔨 Android Auto	
Calendar	
Camera	
O Chrome	
Clock	•
Contacts	
Digital Wellbeing	
🛆 Drive	
Duo	
Files	
Files by Google	
🙆 Gboard	
M Gmail	
G Google	

17

15. Google

Novel coronavirus pneumonia can be monitored by real-time login of Google account, backup, security, parental control account service, traffic and message, automatic filling, device connection, setup and recovery.

16. System

You can set wireless upgrade, language and input method, date and time, backup, reset options, and debugging related to developer options (enter the location of mobile phone and version number for 7 consecutive clicks).

15:08	¢ III Ö		€ 🗅
\leftarrow	Google	0	÷
	© Sign in to your Google Account		
	COVID-19 SUPPORT		
۲	COVID-19 Exposure Notifications Off		
	SERVICES ON THIS DEVICE		
	Ads		
	Auto-fill		
	Backup		
	Devices and sharing		
	Find My Device		
	Mobile data and messaging		
	Parental controls		
	Personalise using shared data		
	Set up and restore		
	< • I		



1) Languages & input

Other languages can be added and switched, and virtual keyboard and physical keyboard can be set.

16 T		滚 自729
<u>,</u>	Languages & input	۹
×A	Languages English (United States) and Simplified Chinese (China)	
	KEYBOARDS	
	On-screen keyboard Gboard and Google voice typing	
	Physical keyboard Not connected	
~	Advanced Tools, Pointer speed, Text-to-speech output	
		8

2) Date & time

You can manually set the date and time, or use the network to automatically obtain the date and time, and you can set the 24-hour display.



19

3) Gestures You can quickly turn on the camera (press the power twice) through gesture settings. The system navigation can switch between gesture navigation and three button navigation, and vibrate when you call (press the power and volume + at the same time).



4) Reset options

You can reset WLAN, mobile data network and Bluetooth settings, Application preferences can be reset and factory settings can be restored.



17. About Tablet

View status information, device models, Android version / Android patch level, base band version (mobile network module model), kernel version, software version number, etc.

